

MV887030/31/32/33/40A

Short Range Wireless Waveform Options for the MT8870A



Operation Manual

MV887030A/ 31A/ 32A/ 33A/ 40A Short Range Wireless Waveform Options for the MT8870A

Safety Symbols

To prevent risk of personal injury or loss related to equipment malfunction, Anritsu Corporation uses the following safety symbols to indicate safety-related information. Ensure that you clearly understand the meanings of the symbols BEFORE using the equipment. Some or all of the following symbols may be used on all Anritsu equipment. In addition, there may be other labels attached to products that are not shown in the diagrams in this manual.

Symbols Used in Manuals



DANGER

This indicates a very dangerous procedure that could result in serious injury or death if not performed properly.



WARNING

This indicates a hazardous procedure that could result in serious injury or death if not performed properly.



CAUTION

This indicates a hazardous procedure or danger that could result in light-to-severe injury, or loss related to equipment malfunction if proper precautions are not taken.

Safety Symbols Used on Equipment and in Manuals

The following safety symbols are used inside or on the equipment near operation locations to provide information about safety items and operation precautions. Ensure that you clearly understand the meanings of the symbols and take the necessary precautions BEFORE using the equipment..



This indicates a prohibited operation. The prohibited operation is indicated symbolically in or near the barred circle.



This indicates an obligatory safety precaution. The obligatory operation is indicated symbolically in or near the circle.



This indicates a warning or caution. The contents are indicated symbolically in or near the triangle.



This indicates a note. The contents are described in the box.



These indicate that the marked part should be recycled.

Equipment Certificate

Anritsu Corporation guarantees that this equipment was inspected at shipment and meets the published specifications.

Anritsu Warranty

- During the warranty period, Anritsu Corporation will repair or exchange this software free-of-charge if it proves defective when used as described in the operation manual.
- The warranty period is 6 months from the purchase date.
- The warranty period after repair or exchange will remain 6 months from the original purchase date, or 30 days from the date of repair or exchange, depending on whichever is longer.
- This warranty does not cover damage to this software caused by Acts of God, natural disasters, and misuse or mishandling by the customer.

In addition, this warranty is valid only for the original equipment purchaser. It is not transferable if the equipment is resold.

Anritsu Corporation shall assume no liability for injury or financial loss of the customer due to the use of or a failure to be able to use this equipment.

Anritsu Corporation Contact

If a malfunction occurs, contact an Anritsu Service and Sales office.

Contact information is listed on the last page of the printed version of this manual, and is available in a separate file on the PDF version.

Notes On Export Management

This product and its manuals may require an Export License or approval by the government of the product country of origin for re-export from your country.

Before you export this product or any of its manuals, please contact Anritsu Company to confirm whether or not these items are export-controlled.

When disposing of export-controlled items, the products and manuals need to be broken or shredded to such a degree that they cannot be unlawfully used for military purposes.

Software End-User License Agreement (EULA)

Please read this Software End-User License Agreement (hereafter this EULA) carefully before using (includes executing, copying, registering, etc.) this software (includes programs, databases, scenarios, etc., used to operate, set, etc., Anritsu electronic equipment). By reading this EULA and using this software, you are agreeing to be bound by the terms of its contents and Anritsu Corporation (hereafter Anritsu) hereby grants you the right to use this Software with the Anritsu-specified equipment (hereafter Equipment) for the purposes set out in this EULA.

1. Grant of License and Limitations

- a. Regardless of whether this Software was purchased from or provided free-of-charge by Anritsu, you agree not to rent, lease, lend, or otherwise distribute this Software to third parties and further agree not to disassemble, recompile, reverse engineer, modify, or create derivative works of this Software.
- b. You may make one copy of this Software for backup purposes only.
- c. You are not permitted to reverse engineer this software.
- d. This EULA allows you to install one copy of this Software on one piece of Equipment.

2. Disclaimers

To the extent not prohibited by law, in no event shall Anritsu be liable for personal injury, or any incidental, special, indirect or consequential damages whatsoever, including, without limitation, damages for loss of profits, loss of data, business interruption or any other commercial damages or losses, arising out of or related to your use or inability to use this Software.

3. Limitation of Liability

- a. If a fault (bug) is discovered in this Software, preventing operation as described in the operation manual or specifications whether or not the customer uses this software as described in the manual, Anritsu shall at its own discretion, fix the bug, or exchange the software, or suggest a workaround, free-of-charge. However, notwithstanding the above, the following items shall be excluded from repair and warranty.
 - i. If this Software is deemed to be used for purposes not described in the operation manual or specifications.
 - ii. If this Software is used in conjunction with other non-Anritsu-approved software.
 - iii. Recovery of lost or damaged data.
 - iv. If this Software or the Equipment has been modified, repaired, or otherwise altered without Anritsu's prior approval.
 - v. For any other reasons out of Anritsu's direct control and responsibility, such as but not limited to, natural disasters, software virus infections, etc.
- b. Expenses incurred for transport, hotel, daily allowance, etc., for on-site repairs by Anritsu engineers necessitated by the above faults shall be borne by you.
- c. The warranty period for faults listed in article 3a above covered by this EULA shall be either 6 months from the date of purchase of this Software or 30 days after the date of repair, whichever is longer.

4. Export Restrictions

You may not use or otherwise export or re-export directly or indirectly this Software except as authorized by Japanese and United States law. In particular, this software may not be exported or re-exported (a) into any Japanese or US embargoed countries or (b) to anyone on the Japanese or US Treasury Department's list of Specially Designated Nationals or the US Department of Commerce Denied Persons List or Entity List. By using this Software, you warrant that you are not located in any such country or on any such list. You also agree that you will not use this Software for any purposes prohibited by Japanese and US law, including, without limitation, the development, design and manufacture or production of missiles or nuclear, chemical or biological weapons of mass destruction.

5. Termination

Anritsu shall deem this EULA terminated if you violate any conditions described herein. This EULA shall also be terminated if the conditions herein cannot be continued for any good reason, such as violation of copyrights, patents, or other laws and ordinances.

6. Reparations

If Anritsu suffers any loss, financial or otherwise, due to your violation of the terms of this EULA, Anritsu shall have the right to seek proportional damages from you.

7. Responsibility after Termination

Upon termination of this EULA in accordance with item 5, you shall cease all use of this Software immediately and shall as directed by Anritsu either destroy or return this Software and any backup copies, full or partial, to Anritsu.

8. Dispute Resolution

If matters of dispute or items not covered by this EULA arise, they shall be resolved by negotiations in good faith between you and Anritsu.

9. Court of Jurisdiction

This EULA shall be interpreted in accordance with Japanese law and any disputes that cannot be resolved by negotiation described in Article 8 shall be settled by the Japanese courts.

CE Conformity Marking

Anritsu affixes the CE conformity marking to the following product(s) in accordance with Council Decision 768/2008/EC to indicate that they conform to the EMC and LVD directives of the European Union.



CE Marking

1. Product Model

Software:

MV887030A WLAN 802.11b/g/a/n Waveforms

MV887031A WLAN 802.11ac Waveforms

MV887032A WLAN 802.11p Waveforms

MV887033A WLAN 802.11ax Waveforms

MV887040A Bluetooth Waveforms

2. Applied Directive and Standards

When the MV887030A WLAN 802.11b/g/a/n Waveforms, MV887031A WLAN 802.11ac Waveforms, MV887032A WLAN 802.11p Waveforms, MV887033A WLAN 802.11ax Waveforms, or MV887040A Bluetooth Waveforms is installed in the MU887000A and MT8870A, the applied directive and standards of this unit conform to those of the MT8870A Universal Wireless Test Set.

Note on Main Frame

Contact Anritsu for the latest information about the MT8870A Universal Wireless Test Set to be used with the MV887030A WLAN 802.11b/g/a/n Waveforms, MV887031A WLAN 802.11ac Waveforms, MV887032A WLAN 802.11p Waveforms, MV887033A WLAN 802.11ax Waveforms, or MV887040A Bluetooth Waveforms.

RCM Conformity Marking

Anritsu affixes the RCM mark to the following product(s) in accordance with the regulations to indicate that they conform to the EMC framework of Australia/New Zealand.



RCM Marking

1. Product Model

Software:

MV887030A WLAN 802.11b/g/a/n Waveforms

MV887031A WLAN 802.11ac Waveforms

MV887032A WLAN 802.11p Waveforms

MV887033A WLAN 802.11ax Waveforms

MV887040A Bluetooth Waveforms

2. Applied Directive and Standards

When the MV887030A WLAN 802.11b/g/a/n Waveforms, MV887031A WLAN 802.11ac Waveforms, MV887032A WLAN 802.11p Waveforms, MV887033A WLAN 802.11ax Waveforms, or MV887040A Bluetooth Waveforms is installed in the MU887000A and MT8870A, the applied directive and standards of this unit conform to those of the MT8870A Universal Wireless Test Set.

Note on Main Frame

Contact Anritsu for the latest information about the MT8870A Universal Wireless Test Set to be used with the MV887030A WLAN 802.11b/g/a/n Waveforms, MV887031A WLAN 802.11ac Waveforms, MV887032A WLAN 802.11p Waveforms, MV887033A WLAN 802.11ax Waveforms, or MV887040A Bluetooth Waveforms.

Table of Contents

Table of Contents 1

Chapter 1—General Information

| | | |
|-----|--------------------------------|-----|
| 1-1 | About this Manual | 1-1 |
| 1-2 | SRW Receiver Testing | 1-1 |

Chapter 2—Using the CombiView VSG Tool

| | | |
|-----|--|-----|
| 2-1 | Receiver Testing | 2-1 |
| 2-2 | Configuring and Running Receiver Tests | 2-2 |
| 2-3 | Calculating the Error Rate | 2-3 |

Chapter 3—Using Remote Commands

| | | |
|-----|--------------------------------------|-----|
| 3-1 | Overview | 3-1 |
| 3-2 | Calculating the Error Rate | 3-2 |

Chapter 4—Waveform Files

| | | |
|-----|--|------|
| 4-1 | 802.11a/b/g/n Waveform Patterns (option MV887030A) | 4-1 |
| 4-2 | 802.11ac Waveform Patterns (option MV887031A) | 4-4 |
| 4-3 | 802.11p Waveform Patterns (option MV887032A) | 4-6 |
| 4-4 | 802.11ax Waveform Patterns (option MV887033A) | 4-7 |
| 4-5 | WLAN Packet Definition | 4-8 |
| 4-6 | Bluetooth Waveform Patterns (option MV887040A) | 4-9 |
| 4-7 | Bluetooth Packet Definition | 4-11 |
| 4-8 | Zero Waveform Patterns | 4-11 |

Appendix A—Specification

| | | |
|-----|---------------------|-----|
| A-1 | MV887030A | A-1 |
| A-2 | MV887031A | A-2 |
| A-3 | MV887032A | A-2 |
| A-4 | MV887033A | A-2 |
| A-5 | MV887040A | A-3 |

Table of Contents (Continued)

Chapter 1 — General Information

1-1 About this Manual

This manual provides details of the short range wireless (SRW) waveforms for use with the MT8870A Universal Wireless Test Set.

The waveform files can be transmitted from the MT8870A to the device under test (DUT) for use in SRW receiver testing.

There are three SRW waveform packages:

- WLAN 802.11a/b/g/n (MV887030A)
- WLAN 802.11ac (MV887031A)
- WLAN 802.11p (MV887032A)
- WLAN 802.11ax (MV887033A)
- Bluetooth BR/EDR/LE (MV887040A, MV887040A-001 (in case of more than 37 bytes payload))
- Bluetooth 2LE (MV887040A, MV887040A-002, MV887040A-001 (in case of more than 37 bytes payload))
- Bluetooth BLR (MV887040A, MV887040A-003, MV887040A-001 (in case of more than 37 bytes payload))

Each package contains a selection of waveform files that have been pre-configured at differing standards, data rates, and modulation patterns.

1-2 SRW Receiver Testing

Waveform file selection and transmission to the DUT can be performed in two ways:

- Using Vector Signal Generator (VSG) tool within CombiView. Refer to chapter 2 for details.
- Using remote SCPI commands to directly control the vector signal generator application within the MT8870A module. Refer to chapter 3 for details.

In both cases, the receiver sensitivity of the DUT is calculated using the chipset vendor's host control software to read the number of received packets.

Chapter 2 — Using the CombiView VSG Tool

2-1 Receiver Testing

CombiView includes the vector signal generator (VSG) to provide receiver testing functionality for the CW, wireless LAN, and *Bluetooth* standards.

To use the VSG you must purchase and register the appropriate MV8870xxA waveform option. Three options are available:

- Option MV887030A: Waveform files for WLAN 802.11b/g/n/a
- Option MV887031A: Waveform files for WLAN 802.11ac
- Option MV887032A: Waveform files for WLAN 802.11p
- Option MV887033A: Waveform files for WLAN 802.11ax
- Option MV887040A: Waveform files for *Bluetooth*

To use Bluetooth Low Energy signal more than 37 bytes payload, you also must purchase the option below.

- Option MV887040A-001: Waveform files for Bluetooth LE more than 37 bytes payload

To use Bluetooth Low Energy 2Mbps (2LE) signal, you also must purchase the option below.

- Option MV887040A-002: Waveform files for Bluetooth 2LE

To use Bluetooth Low Energy Long Range (BLR) signal, you also must purchase the option below.

- Option MV887040A-003: Waveform files for Bluetooth BLR

Each optional package contains a selection of waveform files that have been pre-configured at differing standards, data rates, and modulation patterns.

| | |
|-------------|---|
| Note | A full list of the waveform files provided with each SRW option is provided in chapter 4. |
|-------------|---|

During receiver testing, the Vector Signal Generator tool is used to select a waveform file and to transmit a defined sequence of packets to the DUT receiver.

The receiver sensitivity is calculated using the chipset vendor's software to count the number of frames or packets received in comparison to the number sent.

2-2 Configuring and Running Receiver Tests

1. Within CombiView, at **VSG**, select the port being used to connect to the DUT.
2. Select **VSG > Configure VSG** to open the VSG Settings window shown below.




Figure 2-1. VSG Settings

3. At **Sync Mode** select **SISO** unless doing true MIMO testing. Refer to the CombiView Operation Manual for full details.
4. At **Modulation** select **ARB**.
5. At **Waveform File Type**, select the wireless standard.
6. At **Waveform File**, select the waveform to be transmitted.
7. At **Pattern**, set the data pattern.

Note

Most waveform files for SRW applications contain only one pattern. However files designed for MIMO testing may contain two or more patterns that correspond to the spatial streams comprising the MIMO signal. To transmit this kind of signal you use the same waveform file on each module (spatial stream) and select a different pattern on each module's VSG. For True MIMO receiver testing, the VSGs must be synchronized. See Chapter 10 of the *CombiView Short Range Wireless Applet Operation Manual* (M-W3618AE) for details.

8. Set **frequency** or **channel**.
9. If required, select **Track VSA**. If selected, changes to the VSG frequency are communicated to the VSA, and changes to the VSA frequency are communicated to the VSG. If cleared, the VSA and VSG frequency settings are independent. Note that the VSA cannot be set to frequencies below 1.9 GHz when no MX887032A license.
10. Set a specific **Number of Packets** to be transmitted or select **Continuous** to play the waveform repeatedly until you click **Stop**.
11. Set the transmission power.
12. Click **Transmit** to start transmission of the waveform to the DUT.

2-3 Calculating the Error Rate

Receiver sensitivity is calculated using the chipset vendor's software to count the number of packets or bits received in comparison to the number sent.

Bluetooth Measurements

The receiver sensitivity for *Bluetooth* basic rate and enhanced data rate signals is based on the calculation of Bit Error Rate (BER). BER is an expression of the number of bits that were received in error and is calculated using the formula below:

$$(1 - (\text{Number of bits correctly received} / \text{Number of bits sent})) \times 100\%.$$

The receiver sensitivity for *Bluetooth* low energy signals is based on the calculation of Packet Error Rate (PER). PER is an expression of the number of packets that were received in error and is calculated using the formula below:

$$(1 - (\text{Number of packets correctly received} / \text{Number of packets sent})) \times 100\%.$$

WLAN Measurements

DUT receiver measurements are based on the calculation of Packet Error Rate (PER) or Frame Reception Rate (FRR).

PER is an expression of the number of packets that were received in error and is calculated using the formula below:

$$(1 - (\text{Number of packets correctly received} / \text{Number of packets sent})) \times 100\%.$$

FRR is an expression of the number of packets that were successfully received. FRR is specified by the CTIA and Wi-Fi Alliance in the CWG Test Plan used to evaluate the RF Performance of Wi-Fi Mobile Converged Devices. FRR is calculated using the formula below:

$$(\text{Number of packets correctly received} / \text{Number of packets sent}) \times 100\%.$$

Chapter 3 — Using Remote Commands

3-1 Overview

Receiver tests can be performed using remote SCPI commands to control the vector signal generator application within the MT8870A module.

The example below shows how to select a *Bluetooth* waveform file (provided with MV887040A) and output it from port 1 at -70 dBm on a frequency of 2402 MHz.

| | |
|-------------|---|
| Note | Further details on the vector signal generator application and the modes of operation can be found in the MU887000A TRX Test Module Operation Manual. |
|-------------|---|

1. Set the VSG operation mode to “normal” for use with remote commands.
:SOURce:GPRF:GENerator:MODE NORMal
2. Set the frequency to 2402 MHz.
:SOURce:GPRF:GENerator:RFSetting:FREQuency 2402MHz
3. Set the level to -70 dBm.
:SOURce:GPRF:GENerator:RFSettings:LEVel -70
4. Turn on modulation.
:SOURce:GPRF:GENerator:BBMode ARB
5. Load the waveform file to memory.
:SOURce:GPRF:GENerator:ARB:FILE:LOAD “MV887040A_DH3_3SlotOff”
6. Select port 1 as the output port.
:ROUte:PORT:CONNect:DIRection PORT2, PORT1
7. Turn on signal output.
:SOURce:GPRF:GENerator:STATe ON
8. Check that the output level is within acceptable limits.
:SOURce:GPRF:GENerator:RFSettings:LEVel:SETTing?
9. Stop the signal output.
:SOURce:GPRF:GENerator:STATe OFF

| | |
|-------------|--|
| Note | Refer to the MU887000A TRX Test Module Operation Manual for further information about controlling the VSG application. |
|-------------|--|

3-2 Calculating the Error Rate

Receiver sensitivity is calculated by using the chipset vendor's software to count the number of packets or bits received in comparison to the number sent.

Bluetooth Measurements

The receiver sensitivity for *Bluetooth* basic rate and enhanced data rate signals is based on the calculation of Bit Error Rate (BER). BER is an expression of the number of bits that were received in error and is calculated using the formula below:

$(1 - (\text{Number of bits correctly received} / \text{Number of bits sent})) \times 100\%$.

The receiver sensitivity for *Bluetooth* low energy signals is based on the calculation of Packet Error Rate (PER). PER is an expression of the number of packets that were received in error and is calculated using the formula below:

$(1 - (\text{Number of packets correctly received} / \text{Number of packets sent})) \times 100\%$.

WLAN Measurements

DUT receiver measurements are based on the calculation of Packet Error Rate (PER) or Frame Reception Rate (FRR).

PER is an expression of the number of packets that were received in error and is calculated using the formula below:

$(1 - (\text{Number of packets correctly received} / \text{Number of packets sent})) \times 100\%$.

FRR is an expression of the number of packets that were successfully received. FRR is specified by the CTIA and Wi-Fi Alliance in the CWG Test Plan used to evaluate the RF Performance of Wi-Fi Mobile Converged Devices. FRR is calculated using the formula below:

$(\text{Number of packets correctly received} / \text{Number of packets sent}) \times 100\%$.

Chapter 4 — Waveform Files

4-1 802.11a/b/g/n Waveform Patterns (option MV887030A)

Note

All 802.11a/b/g/n waveforms are prefixed with MV887030A_.
Waveforms ending in “_Q” are customer-variant files.

802.11b

Table 4-1. 802.11b WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|---------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| b_11_1024L | 11 | | 1024 | b | Long | - |
| b_5P5_1024L | 5.5 | | 1024 | b | Long | - |
| b_5P5_100L | 5.5 | | 100 | b | Long | - |
| b_2_100L | 2 | | 100 | b | Long | - |
| b_2_1024L / | 2 | | 1024 | b | Long | - |
| b_1_100L | 1 | | 100 | b | Long | - |
| b_1_1024L / | 1 | | 1024 | b | Long | - |
| b_2_100S_Q | 2 | | 100 | b | Short | - |
| b_2_1024S_Q | 2 | | 1024 | b | Short | - |
| b_5P5_100S_Q | 5.5 | | 100 | b | Short | - |
| b_5P5_1024S_Q | 5.5 | | 1024 | b | Short | - |
| b_11_100S_Q | 11 | | 100 | b | Short | - |
| b_11_1024S_Q | 11 | | 1024 | b | Short | - |

802.11a/g

Table 4-2. 802.11a/g WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| ag_54_1024 | 54 | | 1024 | b | - | - |
| ag_54_1000 | 54 | | 1000 | b | - | - |
| ag_48_1000 | 48 | | 1000 | b | - | - |
| ag_36_1000 | 36 | | 1000 | b | - | - |
| ag_24_1000 | 24 | | 1000 | b | - | - |

Table 4-2. 802.11a/g WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| ag_18_1000 | 18 | | 1000 | b | - | - |
| ag_12_1000 | 12 | | 1000 | b | - | - |
| ag_9_100 | 9 | | 100 | b | - | - |
| ag_9_1000 | 9 | | 1000 | b | - | - |
| ag_6_100 | 6 | | 100 | b | - | - |
| ag_6_1000 | 6 | | 1000 | b | - | - |

802.11n**Table 4-3.** 802.11n WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|-----------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| n_MCS7_20_4096L | MCS7 | 20 | 4096 | b | Long | - |
| n_MCS7_20_4096S | MCS7 | 20 | 4096 | b | Short | - |
| n_MCS7_20_1024L | MCS7 | 20 | 1024 | b | Long | - |
| n_MCS7_40_4096L | MCS7 | 40 | 4096 | b | Long | - |
| n_MCS7_40_4096S | MCS7 | 40 | 4096 | b | Short | - |
| n_MCS7_40_1024L | MCS7 | 40 | 1024 | b | Long | - |
| n_MCS6_20_4096L | MCS6 | 20 | 4096 | b | Long | - |
| n_MCS6_40_4096L | MCS6 | 40 | 4096 | b | Long | - |
| n_MCS5_20_4096L | MCS5 | 20 | 4096 | b | Long | - |
| n_MCS5_40_4096L | MCS5 | 40 | 4096 | b | Long | - |
| n_MCS4_20_4096L | MCS4 | 20 | 4096 | b | Long | - |
| n_MCS4_20_500L | MCS4 | 20 | 500 | b | Long | - |
| n_MCS4_40_4096L | MCS4 | 40 | 4096 | b | Long | - |
| n_MCS4_40_500L | MCS4 | 40 | 500 | b | Long | - |
| n_MCS3_20_4096L | MCS3 | 20 | 4096 | b | Long | - |
| n_MCS3_20_500L | MCS3 | 20 | 500 | b | Long | - |
| n_MCS3_40_4096L | MCS3 | 40 | 4096 | b | Long | - |
| n_MCS3_40_500L | MCS3 | 40 | 500 | b | Long | - |
| n_MCS2_20_4096L | MCS2 | 20 | 4096 | b | Long | - |
| n_MCS2_20_500L | MCS2 | 20 | 500 | b | Long | - |
| n_MCS2_40_4096L | MCS2 | 40 | 4096 | b | Long | - |
| n_MCS2_40_500L | MCS2 | 40 | 500 | b | Long | - |

Table 4-3. 802.11n WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|------------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| n_MCS1_20_4096L | MCS1 | 20 | 4096 | b | Long | - |
| n_MCS1_20_500L | MCS1 | 20 | 500 | b | Long | - |
| n_MCS1_40_4096L | MCS1 | 40 | 4096 | b | Long | - |
| n_MCS1_40_500L | MCS1 | 40 | 500 | b | Long | - |
| n_MCS0_20_4096L | MCS0 | 20 | 4096 | b | Long | - |
| n_MCS0_20_500L | MCS0 | 20 | 500 | b | Long | - |
| n_MCS0_40_4096L | MCS0 | 40 | 4096 | b | Long | - |
| n_MCS0_40_500L | MCS0 | 40 | 500 | b | Long | - |
| n_MCS32_40_4096L | MCS32 | 40 | 4096 | b | Long | - |

4-2 802.11ac Waveform Patterns (option MV887031A)

Note All 802.11ac waveforms are prefixed with MV887031A_.

Table 4-4. 802.11ac WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|-------------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| ac_MCS9_40_4096L | MCS9 | 40 | 4096 | b | Long | 1 |
| ac_MCS9_40_1024L | MCS9 | 40 | 1024 | b | Long | 1 |
| ac_MCS9_80_4096L | MCS9 | 80 | 4096 | b | Long | 1 |
| ac_MCS9_80_1024L | MCS9 | 80 | 1024 | b | Long | 1 |
| ac_MCS9_160_4096L | MCS9 | 160 | 4096 | b | Long | 1 |
| ac_MCS8_20_4096L | MCS8 | 20 | 4096 | b | Long | 1 |
| ac_MCS8_20_1024L | MCS8 | 20 | 1024 | b | Long | 1 |
| ac_MCS8_40_4096L | MCS8 | 40 | 4096 | b | Long | 1 |
| ac_MCS8_40_1024L | MCS8 | 40 | 1024 | b | Long | 1 |
| ac_MCS8_80_4096L | MCS8 | 80 | 4096 | b | Long | 1 |
| ac_MCS8_80_1024L | MCS8 | 80 | 1024 | b | Long | 1 |
| ac_MCS8_160_4096L | MCS8 | 160 | 4096 | b | Long | 1 |
| ac_MCS7_20_4096L | MCS7 | 20 | 4096 | b | Long | 1 |
| ac_MCS7_40_4096L | MCS7 | 40 | 4096 | b | Long | 1 |
| ac_MCS7_80_4096L | MCS7 | 80 | 4096 | b | Long | 1 |
| ac_MCS7_160_4096L | MCS7 | 160 | 4096 | b | Long | 1 |
| ac_MCS6_20_4096L | MCS6 | 20 | 4096 | b | Long | 1 |
| ac_MCS6_40_4096L | MCS6 | 40 | 4096 | b | Long | 1 |
| ac_MCS6_80_4096L | MCS6 | 80 | 4096 | b | Long | 1 |
| ac_MCS6_160_4096L | MCS6 | 160 | 4096 | b | Long | 1 |
| ac_MCS5_20_4096L | MCS5 | 20 | 4096 | b | Long | 1 |
| ac_MCS5_40_4096L | MCS5 | 40 | 4096 | b | Long | 1 |
| ac_MCS5_80_4096L | MCS5 | 80 | 4096 | b | Long | 1 |
| ac_MCS5_160_4096L | MCS5 | 160 | 4096 | b | Long | 1 |
| ac_MCS4_20_4096L | MCS4 | 20 | 4096 | b | Long | 1 |
| ac_MCS4_20_500L | MCS4 | 20 | 500 | b | Long | 1 |
| ac_MCS4_40_4096L | MCS4 | 40 | 4096 | b | Long | 1 |
| ac_MCS4_40_500L | MCS4 | 40 | 500 | b | Long | 1 |
| ac_MCS4_80_4096L | MCS4 | 80 | 4096 | b | Long | 1 |
| ac_MCS4_80_500L | MCS4 | 80 | 500 | b | Long | 1 |
| ac_MCS4_160_4096L | MCS4 | 160 | 4096 | b | Long | 1 |

Table 4-4. 802.11ac WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|-------------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| ac_MCS4_160_500L | MCS4 | 160 | 500 | b | Long | 1 |
| ac_MCS3_20_4096L | MCS3 | 20 | 4096 | b | Long | 1 |
| ac_MCS3_20_500L | MCS3 | 20 | 500 | b | Long | 1 |
| ac_MCS3_40_4096L | MCS3 | 40 | 4096 | b | Long | 1 |
| ac_MCS3_40_500L | MCS3 | 40 | 500 | b | Long | 1 |
| ac_MCS3_80_4096L | MCS3 | 80 | 4096 | b | Long | 1 |
| ac_MCS3_80_500L | MCS3 | 80 | 500 | b | Long | 1 |
| ac_MCS3_160_4096L | MCS3 | 160 | 4096 | b | Long | 1 |
| ac_MCS3_160_500L | MCS3 | 160 | 500 | b | Long | 1 |
| ac_MCS2_20_4096L | MCS2 | 20 | 4096 | b | Long | 1 |
| ac_MCS2_20_500L | MCS2 | 20 | 500 | b | Long | 1 |
| ac_MCS2_40_4096L | MCS2 | 40 | 4096 | b | Long | 1 |
| ac_MCS2_40_500L | MCS2 | 40 | 500 | b | Long | 1 |
| ac_MCS2_80_4096L | MCS2 | 80 | 4096 | b | Long | 1 |
| ac_MCS2_80_500L | MCS2 | 80 | 500 | b | Long | 1 |
| ac_MCS2_160_4096L | MCS2 | 160 | 4096 | b | Long | 1 |
| ac_MCS2_160_500L | MCS2 | 160 | 500 | b | Long | 1 |
| ac_MCS1_20_4096L | MCS1 | 20 | 4096 | b | Long | 1 |
| ac_MCS1_20_500L | MCS1 | 20 | 500 | b | Long | 1 |
| ac_MCS1_40_4096L | MCS1 | 40 | 4096 | b | Long | 1 |
| ac_MCS1_40_500L | MCS1 | 40 | 500 | b | Long | 1 |
| ac_MCS1_80_4096L | MCS1 | 80 | 4096 | b | Long | 1 |
| ac_MCS1_80_500L | MCS1 | 80 | 500 | b | Long | 1 |
| ac_MCS1_160_4096L | MCS1 | 160 | 4096 | b | Long | 1 |
| ac_MCS1_160_500L | MCS1 | 160 | 500 | b | Long | 1 |
| ac_MCS0_20_4096L | MCS0 | 20 | 4096 | b | Long | 1 |
| ac_MCS0_20_500L | MCS0 | 20 | 500 | b | Long | 1 |
| ac_MCS0_40_4096L | MCS0 | 40 | 4096 | b | Long | 1 |
| ac_MCS0_40_500L | MCS0 | 40 | 500 | b | Long | 1 |
| ac_MCS0_80_4096L | MCS0 | 80 | 4096 | b | Long | 1 |
| ac_MCS0_80_500L | MCS0 | 80 | 500 | b | Long | 1 |
| ac_MCS0_160_4096L | MCS0 | 160 | 4096 | b | Long | 1 |
| ac_MCS0_160_500L | MCS0 | 160 | 500 | b | Long | 1 |

4-3 802.11p Waveform Patterns (option MV887032A)

Table 4-5. 802.11p WLAN Waveforms

| Waveform | Data rates / modulation | Bandwidth (MHz) | Packet length (byte) | Broadcast / Unicast | Preamble / Guard Interval | Nss |
|---------------|-------------------------|-----------------|----------------------|---------------------|---------------------------|-----|
| p_54_20_1000 | 54 | 20 | 1000 | b | - | - |
| p_48_20_1000 | 48 | 20 | 1000 | b | - | - |
| p_36_20_1000 | 36 | 20 | 1000 | b | - | - |
| p_24_20_1000 | 24 | 20 | 1000 | b | - | - |
| p_18_20_1000 | 18 | 20 | 1000 | b | - | - |
| p_12_20_1000 | 12 | 20 | 1000 | b | - | - |
| p_9_20_1000 | 9 | 20 | 1000 | b | - | - |
| p_6_20_1000 | 6 | 20 | 1000 | b | - | - |
| p_27_10_1000 | 27 | 10 | 1000 | b | - | - |
| p_24_10_1000 | 24 | 10 | 1000 | b | - | - |
| p_18_10_1000 | 18 | 10 | 1000 | b | - | - |
| p_12_10_1000 | 12 | 10 | 1000 | b | - | - |
| p_9_10_1000 | 9 | 10 | 1000 | b | - | - |
| p_6_10_1000 | 6 | 10 | 1000 | b | - | - |
| p_4p5_10_1000 | 4.5 | 10 | 1000 | b | - | - |
| p_3_10_1000 | 3 | 10 | 1000 | b | - | - |
| p_13p5_5_1000 | 13.5 | 5 | 1000 | b | - | - |
| p_12_5_1000 | 12 | 5 | 1000 | b | - | - |
| p_9_5_1000 | 9 | 5 | 1000 | b | - | - |
| p_6_5_1000 | 6 | 5 | 1000 | b | - | - |
| p_4p5_5_1000 | 4.5 | 5 | 1000 | b | - | - |
| p_3_5_1000 | 3 | 5 | 1000 | b | - | - |
| p_2p25_5_1000 | 2.25 | 5 | 1000 | b | - | - |
| p_1p5_5_1000 | 1.5 | 5 | 1000 | b | - | - |

4-4 802.11ax Waveform Patterns (option MV887033A)

Note All 802.11ax waveforms are prefixed with MV887033A_.

Table 4-6. 802.11ax WLAN Waveforms

| Waveform | PPDU format | Data rate / modulation | Bandwidth (MHz) | PDSU length (Octet) | FEC encoders | DCM | Nss |
|---------------------------------|-------------|------------------------|-----------------|---------------------|--------------|-----|-----|
| ax_SU_MCS11_80_4096_08LTFx2L *1 | HE-SU | MCS11 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS10_80_4096_08LTFx2L *1 | HE-SU | MCS10 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS9_80_4096_08LTFx2L *1 | HE-SU | MCS9 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS8_80_4096_08LTFx2L *1 | HE-SU | MCS8 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS7_80_4096_08LTFx2L *1 | HE-SU | MCS7 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS6_80_4096_08LTFx2L *1 | HE-SU | MCS6 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS5_80_4096_08LTFx2L *1 | HE-SU | MCS5 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS4_80_4096_08LTFx2L *1 | HE-SU | MCS4 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS3_80_4096_08LTFx2L *1 | HE-SU | MCS3 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS2_80_4096_08LTFx2L *1 | HE-SU | MCS2 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS1_80_4096_08LTFx2L *1 | HE-SU | MCS1 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS0_80_4096_08LTFx2L *1 | HE-SU | MCS0 | 80 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS11_40_4096_08LTFx2L *1 | HE-SU | MCS11 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS10_40_4096_08LTFx2L *1 | HE-SU | MCS10 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS9_40_4096_08LTFx2L *1 | HE-SU | MCS9 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS8_40_4096_08LTFx2L *1 | HE-SU | MCS8 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS7_40_4096_08LTFx2L *1 | HE-SU | MCS7 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS6_40_4096_08LTFx2L *1 | HE-SU | MCS6 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS5_40_4096_08LTFx2L *1 | HE-SU | MCS5 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS4_40_4096_08LTFx2L *1 | HE-SU | MCS4 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS3_40_4096_08LTFx2L *1 | HE-SU | MCS3 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS2_40_4096_08LTFx2L *1 | HE-SU | MCS2 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS1_40_4096_08LTFx2L *1 | HE-SU | MCS1 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS0_40_4096_08LTFx2L *1 | HE-SU | MCS0 | 40 | 4096 | LDPC | Off | 1 |
| ax_SU_MCS11_20_4096_08LTFx2B *1 | HE-SU | MCS11 | 20 | 4096 | BCC | Off | 1 |

Table 4-6. 802.11ax WLAN Waveforms

| Waveform | PPDU format | Data rate / modulation | Bandwidth (MHz) | PDSU length (Octet) | FEC encoders | DCM | Nss |
|---------------------------------|-------------|------------------------|-----------------|---------------------|--------------|-----|-----|
| ax_SU_MCS10_20_4096_08LTFx2B *1 | HE-SU | MCS10 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS9_20_4096_08LTFx2B *1 | HE-SU | MCS9 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS8_20_4096_08LTFx2B *1 | HE-SU | MCS8 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS7_20_4096_08LTFx2B *1 | HE-SU | MCS7 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS6_20_4096_08LTFx2B *1 | HE-SU | MCS6 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS5_20_4096_08LTFx2B *1 | HE-SU | MCS5 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS4_20_4096_08LTFx2B *1 | HE-SU | MCS4 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS3_20_4096_08LTFx2B *1 | HE-SU | MCS3 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS2_20_4096_08LTFx2B *1 | HE-SU | MCS2 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS1_20_4096_08LTFx2B *1 | HE-SU | MCS1 | 20 | 4096 | BCC | Off | 1 |
| ax_SU_MCS0_20_4096_08LTFx2B *1 | HE-SU | MCS0 | 20 | 4096 | BCC | Off | 1 |

*1: non-STBC mode, 800ns GI, 2x HE-LTF.

4-5 WLAN Packet Definition

Idle time before rising edge (us): 0

Idle time after falling edge (us): 30

3 MAC addresses: ff:ff:ff:ff:ff:ff
20:22:22:22:22:02
50:55:55:55:55:05

Payload type: PN9

Scrambled: yes

b Filter type: Gaussian bt=0.5

n/ac PPDU format: mixed

Broadcast: yes

4-6 Bluetooth Waveform Patterns (option MV887040A)

Note

All *Bluetooth* waveforms are prefixed with MV887040A_.
Waveforms ending in “_Q” are customer-variant files.

Table 4-7. Bluetooth Waveforms

| Waveform | Data rate (Mbps) | Modulation | Filter | Packet type |
|---------------------------------|------------------|--------------------|----------------------------|-----------------------|
| DH1* ¹ | 1 | GFSK* ⁴ | Gaussian* ⁵ | DH1 |
| DH3* ¹ | 1 | GFSK* ⁴ | Gaussian* ⁵ | DH3 |
| DH5* ¹ | 1 | GFSK* ⁴ | Gaussian* ⁵ | DH5 |
| 2-DH1* ¹ | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | 2-DH1 |
| 2-DH3* ¹ | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | 2-DH3 |
| 2-DH5* ¹ | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | 2-DH5 |
| 3-DH1* ¹ | 3 | 8-DPSK | Root Nyquist* ⁶ | 3-DH1 |
| 3-DH3* ¹ | 3 | 8-DPSK | Root Nyquist* ⁶ | 3-DH3 |
| 3-DH5* ¹ | 3 | 8-DPSK | Root Nyquist* ⁶ | 3-DH5 |
| GFSK-PN15* ³ | 1 | GFSK* ⁴ | Gaussian* ⁵ | No packet format |
| PI_4_DQPSK-PN15* ³ | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | No packet format |
| 8DPSK-PN15* ³ | 3 | 8DPSK | Root Nyquist* ⁶ | No packet format |
| BLE* ¹ | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLE Reference Signal |
| BLE_CRC_corrupted* ¹ | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLE Reference Signal |
| BLE_255* ¹⁰ | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLE Payload 255 bytes |
| 2LE_37* ¹¹ | 2 | GFSK* ⁹ | Gaussian* ⁵ | 2LE Payload 37 bytes |
| 2LE_255* ^{10,*11} | 2 | GFSK* ⁹ | Gaussian* ⁵ | 2LE Payload 255 bytes |
| BLR_S2_37* ¹² | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLR Payload 37 bytes |
| BLR_S2_255* ^{10,*12} | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLR Payload 255 bytes |
| BLR_S8_37* ¹² | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLR Payload 37 bytes |
| BLR_S8_255* ^{10,*12} | 1 | GFSK* ⁹ | Gaussian* ⁵ | BLR Payload 255 bytes |
| GFSK-PN15_BLE* ³ | 1 | GFSK* ⁹ | Gaussian* ⁵ | No packet format |
| 2-DH1C_Q | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | 2-DH1 |
| 2-DH3C_Q | 2 | $\pi/4$ -DQPSK | Root Nyquist* ⁶ | 2-DH3 |

Table 4-7. Bluetooth Waveforms

| Waveform | Data rate (Mbps) | Modulation | Filter | Packet type |
|----------|------------------|--------------------|----------------------------|----------------------|
| 2-DH5C_Q | 2 | $\pi/4$ -DQPSK | Root Nyquist ^{*6} | 2-DH5 |
| 3-DH1C_Q | 3 | 8-DPSK | Root Nyquist ^{*6} | 3-DH1 |
| 3-DH3C_Q | 3 | 8-DPSK | Root Nyquist ^{*6} | 3-DH3 |
| 3-DH5C_Q | 3 | 8-DPSK | Root Nyquist ^{*6} | 3-DH5 |
| BLE_Q | 1 | GFSK ^{*9} | Gaussian ^{*5} | BLE Reference Signal |
| DH1C_Q | 1 | GFSK ^{*4} | Gaussian ^{*5} | DH1 |
| DH3C_Q | 1 | GFSK ^{*4} | Gaussian ^{*5} | DH3 |
| DH5C_Q | 1 | GFSK ^{*4} | Gaussian ^{*5} | DH5 |

*1: PN9 data is inserted into the payload body.

*2: PN9 data is inserted to all areas that do not have a packet format.

*3: PN15 data is inserted to all areas that do not have a packet format.

*4: Modulation index = 0.32

*5: Bandwidth time (BT) = 0.5

*6: Roll-off rate $\beta = 0.4$

*7: Use in RF-PHY.TS/4.0.0 RCV-LE/CA/07/C (PER Report Integrity) with intentional CRC errors in every other packet is assumed.

*8: Refer to Section 3.11.4.

*9: Modulation index = 0.5

*10: MV887040A-001 is needed.

*11: MV887040A-002 is needed.

*12: MV887040A-003 is needed.

4-7 Bluetooth Packet Definition

Am_addr: 7 (standard waveforms), 0 (_Q waveforms)
 Flow: 1
 Arqn: 0
 Seqn: 0
 Uap: 0x6b
 Lap: 0xc6967e
 Logical channel: 0
 Logical flow: 0

4-8 Zero Waveform Patterns

Note

The zero waveform is included in all of the SRW waveform packages (MV887030A, MV887031A, and MV887040A)

Table 4-8. Zero Waveforms

| Waveform | Output | Pattern Length |
|--------------------------|-----------|----------------|
| ZERO_200000000Hz_100000p | No signal | 500 us |

Appendix A — Specification

A-1 MV887030A

Name

WLAN 802.11b/g/a/n waveforms

Structure

The items below are provided on the product DVD etc. The waveform files are also pre-installed on the MU887000A TRX Test Module.

WLAN 802.11b/g/a/n Waveforms files: 56

WLAN 802.11b/g/a/n Waveforms license files: 1

Operation Manual: 1

EVM

802.11b

Packet Length 1024 byte

Frequency: 2402 MHz to 2484 MHz

Gaussian filter BT 0.5

EVM: ≤ -38 dB rms

802.11g

Packet Length 1000 byte

Frequency: 2402 MHz to 2484 MHz

Operating temperature 20°C to 30°C

EVM: ≤ -40 dB rms

802.11a

Packet Length 1000 byte

Frequency: 4920 MHz to 5825 MHz

Operating temperature 20°C to 30°C

EVM: ≤ -38 dB rms

802.11n (2402 MHz to 2484 MHz)

Packet Length 4096 byte, Long Guard Interval, Channel bandwidth 40 MHz

Operating temperature 20°C to 30°C

EVM: ≤ -40 dB rms

802.11n (4920 MHz to 5825 MHz)

Packet Length 4096 byte, Long Guard Interval, Channel bandwidth 40 MHz

Operating temperature 20°C to 30°C

EVM: ≤ -38 dB rms

A-2 MV887031A

Name

WLAN 802.11ac waveforms

Structure

The items below are provided on the product DVD etc. The waveform files are also pre-installed on the MU887000A TRX Test Module.

WLAN 802.11ac Waveforms files: 65

WLAN 802.11ac Waveforms license files: 1

Operation Manual: 1

A-3 MV887032A

Name

WLAN 802.11p waveforms

Structure

The items below are provided on the product DVD etc. The waveform files are also pre-installed on the MU887000A TRX Test Module.

WLAN 802.11p Waveforms files: 25

WLAN 802.11p Waveforms license files: 1

Operation Manual: 1

A-4 MV887033A

Name

WLAN 802.11ax waveforms

Structure

The items below are provided on the product DVD etc. The waveform files are also pre-installed on the MU887000A TRX Test Module.

WLAN 802.11ax Waveforms files: 36

WLAN 802.11ax Waveforms license files: 1

Operation Manual: 1

A-5 MV887040A

Name

Bluetooth waveforms

Structure

The items below are provided on the product DVD etc. The waveform files are also pre-installed on the MU887000A TRX Test Module.

Bluetooth waveforms files: 33 (including one file for MV887040A-001, two files for MV887040A-002, and four files for MV887040A-003)

Bluetooth waveforms license files: 1

Operation Manual: 1

Deviation

Frequency: 2402 MHz to 2480 MHz

GFSK modulation

Nominal: 1% (+/-0.01 x deviation Hz)

DEVM

Frequency: 2402 MHz to 2480 MHz

$\pi/4$ -DQPSK or 8-DPSK modulation

<5% rms



| | | |
|---|---|--|
| AUSTRALIA ANRITSU PTY. LTD. Unit 21, 21-35 Ricketts Road Mount Waverley Victoria 3168 Australia Telephone: +61-3-9558-8177 Fax: +61-3-9558-8255 | BRAZIL ANRITSU ELETRONICA LTDA. Praça Amadeu Amaral, 27 - 1 Andar 01327-010-Bela Vista-São Paulo-SP Brazil Telephone: +55-11-3283-2511 Fax: +55-11-3288-6940 | CANADA ANRITSU ELECTRONICS LTD. 700 Silver Seven Road, Suite 120, Kanata, ON K2V 1C3, Canada Telephone: +1-613-591-2003 Fax: +1-613-591-1006 |
| CHINA ANRITSU SHANGHAI SERVICE CENTER 2F, 8B-2 Section Factory Building, No. 211, Fu Te Rd. (N). China(Shanghai) Pilot Free Trade Zone, Pudong, Shanghai 200131, P.R. China Telephone: +86-21-5868-0228 Fax: +86-10-5868-0558 | DENMARK ANRITSU A/S Torveporten 2 2500 Valby Denmark Telephone: +45-7211-2200 Fax: +45-7211-2210 | FINLAND ANRITSU AB Teknobulevardi 3-5 FI-01530 Vantaa Finland Telephone: +358-20-741-8100 Fax: +358-20-741-811 |
| FRANCE Anritsu S.A. 12, Avenue du Québec Bâtiment Ires 1- Silic 612, 91140 VILLEBON SUR YVETTE, France Telephone: +33-1-60-92-15-50 Fax: +33-1-64-46-10-65 | GERMANY Anritsu GmbH Nemetschek Haus Konrad-Zuse-Platz 1 81829 München Germany Telephone: +49-89-442308-0 Fax: +49-89-442308-55 | HONG KONG ANRITSU COMPANY LTD. Units 1006-7, 10/F, Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong Telephone: +852-2301-4980 Fax: +852-2301-3545 |
| INDIA ANRITSU India Private Limited 2nd & 3rd Floor, #837/1, Binnamangla 1st Stage Indiranagar, 100ft Road, Bengaluru - 560038 India Telephone: +91-80-4058-1300 Fax: +91-80-4058-1301 | ITALY ANRITSU Sp.A Via Paracelso 4 CD Colleoni Agrate Brianza, 20041 Milano Italy Telephone: +39-39-657021 Fax: +39-39-6056396 | JAPAN Anritsu Corporation 5-1-1 Onna, Atsugi-shi, Kanagawa 243-8555 Japan Telephone: +81-46-223-1111 Fax: +81-46-296-1264 |
| KOREA ANRITSU CORPORATION LTD. 5FL, 235 Pangyoeyeok-ro Bundang-gu, Seongnam-si, Gyeonggi-do, 13494 Korea Telephone: +82-31-696-7750 Fax: +82-31-696-7751 | SINGAPORE ANRITSU PTE. LTD. 11 Chang Cham Road #04-01, Shiro House Singapore 159640 Telephone: +65-6282-2400 Fax: +65-6282-2533 | SWEDEN Anritsu AB Kistagången 20B, 164 40 KISTA, Sweden Telephone: +46-8-534-707-00 Fax: +46-8-534-707-30 |
| TAIWAN ANRITSU CO., LTD. 7F, NO.316, Sec.1 NeiHu Rd., Taipei, 114 Taiwan, R.O.C Telephone: +886-2-8751-1816 Fax: +886-2-8751-1817 | UNITED KINGDOM Anritsu EMEA LTD 200 Capability Green, Luton, Bedfordshire, LU1 3LU U.K. Telephone: +44-1582-433200 Fax: +44-1582-731303 | UNITED STATES ANRITSU COMPANY 1155 East Collins Blvd., Richardson, TX 75081, U.S.A. Toll Free: 1-800-ANRITSU (267-4878) Telephone: +1-972-644-1777 Fax: +1-972-671-1877 |

